



Kitchen Stove



Part #	Ref#	Description	Qty
HH-16	16	Front Frame	1
HH-17	17	Main Door Frame	1
HH-18	18	Main Door Handle	1
HH-19	19	Oven Door Panel	1
HH-20	20	Spring Cover	1
HH-21	21	Spring	1
HH-22	22	Front Cleanout Door	1
HH-24	24	Ash Door	1
HH-25	25	Fuel Door	1
HH-26	26	Small Door Handle	1
HH-27	27	Lever	1
HH-28	28	Connecting Rod	1
HH-29	29	Damper	1
HH-30	30	Top Plate	1
HH-31	31	Fuel Cover Handle	1
HH-32	32	Fuel Cover Handle	1
HH-33	33	Removable Plate	1

HH005



Part #	Ref #	Description	Qty
HH-34	34	Lid Large	4
HH-35	35	Removable Plate	1
HH-37	37	Lid Small	2
HH-38	38	Top Plate Extension	1
HH-39	39	Master Handle	1
HH-41	41	Draft Frame	1
HH-42	42	Draft Control Rear	1
HH-43	43	Draft Control Rear Handle	1
HH-44	44	Rear Boot	1
HH-45	45	Front Boot	1
HH-46	46	Back Side Inside	1
HH-47	47	Back Side Outside	1
HH-48	48	Rear Grate Support	1
HH-49	49	Left Side	1
HH-50	50	Draft Control Side	1
HH-51	51	Grate Side Left	1
HH-52	52	Grate	1
HH-53	53	Ash Plate	1
HH-54	54	Ash Box	1
HH-55	55	Front Grate Support	1
HH-56	56	Grate Side Right	1
HH-57	57	Central Post	1
HH-58	58	Left Heat Plate	1
HH-59	59	Top Heat Plate	1
HH-60	60	Oven Rack	1
HH-61	61	Right Side	1
HH-62	62	Right Heat Plate	1
HH-63	63	Bottom Heat Plate	1
HH-64	64	Air Guide	1
HH-65	65	Bottom Heat Plate	1
HH-66	66	Long Base Rail	2
HH-67	67	Legs	4
HH-68	68	Short Base Rails	2