


When ordering missing or replacement parts,
always provide the following stove information:

Model Number
Part Number
Part Description

HR-6 Parts List



Part #	Ref #	Description	Qty
HR-01	1	Cord, Power Supply	1
HR-02	2	Bushing, Strain Relief	1
HR-03	3	Nut, 8-32 Hex	1
HR-04	4	Fan Motor	1
HR-05	5	Fan Blade	1
HR-06	6	Screw, 8-32x 1-1/4" Machine screw	1
HR-07	7	Steel Spacer	1
HR-08	8	Power Cord Clamp	1
HR-09	9	Jam Nut, #8-32 Nylon Insert	2
HR-10	10	Thermostat	1
HR-11	11	Screw, #8-32x3/8" Pan Head Sheet Metal	8
HR-61	61	Top and Side Weldment	1
HR-62	62	Bottom and Back Weldment	1
HR-63	63	Flue Pipe and Tubing Assembly	1
HR-64	64	Brass Trim	1
HR-12		Capacitor	1