


When ordering missing or replacement parts, always provide the following stove information:

**BX42E  
Parts List**

Model Number  
Part Number  
Part Description



Part #	Ref #	Description	Qty	Part #	Ref #	Description	Qty
42-01	1	Leg	4	42-11	11	Hearth	1
42-02	2	Bottom	1	42-12	12	Damper Collar Assembly	1
42-03	3	Side	2	42-13	13	Handle Assembly	1
42-04	4	Back	1	L-1	14	Lid Lifter	1
42-05	5	Front	1	42-HP	15	Hardware Pack	1
42-06	6	Door	1	42-16	16	S-Hook (for lid lifter)	1
42-07	7	Top	1	42-17	17	Spin Draft	1
42-08	8	Damper, Slide Draft	1	42-18	18	Door Latch	1
42-09	9	Lid	2	GK14	19	Door Gasket (1/4" Fiberglass)	1
42-10	10	Lid Support	1	FG34	none	Gasket Kit, Flat	1