


When ordering missing or replacement parts, always provide the following stove information:

LC-37 Parts List

Model Number
Part Number
Part Description



Ref #	Description	Qty	Ref #	Description	Qty
A	Upper Separation Bar	2	K	Bushing, 27/32"od x 7/16"id x 1/16"	2
B	Back Vertical Support Bar	2	L	Bushing, 1 3/32"od x 1/2"id x 3/32"	2
C	Center Back Vertical Support Bar	1	M	Axle	1
D	Front Vertical Support Bar	2	N	Hex Nut, 12mm x 1.75	2
E	Center Front Vertical Support Bar	1	O	Rubber Wheel, 10" x 1.25" w/ 1/2" Bearing	2
F	Base Support Legs Bar	2	P	Screw, 1/4-20 x 5/8" SKTRHMS	12
G	Separation Bar	2	R	Screw, 1/4-20 x 1" SKTRHMS	6
H	Hood Handle	1			
J	Round Shim	4			